Truck Route – Brokaw



IMPORTANT!!!!!
When entering the facility watch the green and red lights. Pull onto the scale and after vehicle is weighed the green light will flash. After green light is flashed pull off of scale and follow the truck route guide.

PLEASE DRIVE SLOWLY ON TO AND OFF OF THE SCALE. JERKING THE VEHICLE ON THE SCALE CAN DAMAGE THE LOAD CELLS.